| UMASS BOSTON | Environmental Health and Safety |
|------------------|---|
| Safety Guideline | Donning and Doffing Personal Protective Equipment (PPE) |
| | Effective Date: May 2020 |

It is important to don and doff PPE appropriately to ensure personnel protection because PPE could be contaminated with hazardous agents after use.

Procedure:

Don PPE in the following order:

- **1.** Lab coat or gown
- **2.** Respiratory protection (surgical mask, respirator) (if needed)
- **3.** Shoe covers and/or bouffant cap (if needed)
- **4.** Face/eye protection (safety glasses, goggles, face mask)—adjust to fit
- **5.** Gloves—extend to cover wrists of lab coat or gown

Doff PPE in the following order:

- 1. Gloves
 - Avoid touching the outside of the gloves with bare hands
 - Immediately dispose as biohazardous waste
- 2. Face/eye protection (safety glasses, goggles, face mask)
 - Handle by headband or earpiece
 - Place in designated receptacle for decontamination or dispose as biohazardous waste
- 3. Lab coat or gown
 - Unfasten ties/buttons/snaps
 - Remove by touching the inside of the lab coat/gown only
 - Turn inside out
 - Fold or bundle and place in designated receptacle for decontamination or dispose as biohazardous waste

- 4. Respiratory protection (surgical mask, respirator)
 - Grasp bottom then top ties or elastics and remove
 - Place in designated receptacle for decontamination or dispose as biohazardous waste
- 5. Shoe coverings and/or bouffant cap
 - Remove by touching the inside only
 - Immediately dispose as biohazardous waste
- 6. Wash hands with soap and water per the Hand Sanitation SOP

Cautions & Considerations

- ✓ The type of PPE required will vary for different procedures or hazards and is described in lab-specific SOPs
- ✓ Ensure that PPE fits correctly and covers exposed skin
- ✓ Change gloves whenever contaminated or compromised
- ✓ When double gloving, remove and dispose of outer gloves with hands inside the biosafety cabinet then re-don outer gloves after removinghands from the biosafety cabinet
- ✓ When removing PPE, treat the outside of all items as though contaminated
- ✓ Remove PPE and wash hands before entering public areas
- ✓ Keep gloved hands away from face or items that are handled with bare hands
- ✓ Send reusable PPE for laundering only to an approved cleaning company

Resources

- ✓ CDC Fact Sheet "How to remove gloves"
- ✓ CDC Fact Sheet "Sequence for Donning/Doffing Personal Protective Equipment (PPE)"